METAZA ドライバ　インストールガイド（Windows 7）

METAZA ドライバが Windows 7 対応となりました。
ここでは、Windows 7 での METAZA ドライバのインストール方法などについて説明します。

対応エディション

○ **Windows 7 Home Premium (32 ビット版または 64 ビット版)**
○ **Windows 7 Professional (32 ビット版または 64 ビット版)**

※ Windows XP モードでの動作確認は行なっておりません。
※ 最新情報は当社ホームページ（ http://www.rolanddg.co.jp/ ）をご覧ください。

METAZA ドライバをインストールする

お願い
古いバージョンの METAZA ドライバが既にインストールされている場合は、必ず古いバージョンの METAZA ドライバをアンインストールしてから最新の METAZA ドライバをインストールしてください。さもないと、METAZA ドライバが正常に動作しないことがあります。METAZA ドライバのアンインストール方法は、次項の「METAZA ドライバをアンインストールする」をご覧ください。

手順

❶ ① お使いの当社製品（以下、機器）とコンピュータの電源をオフにする。
② 機器とコンピュータ間の接続ケーブルを取り外す。
③ コンピュータの電源をオンにする。

❷ 「管理者」または「Administrators」グループのメンバーとして Windows 7 にログオンする。

❸ 古いバージョンの METAZA ドライバがインストールされている場合は、アンインストールする。
☞「METAZA ドライバをアンインストールする」

❹ Roland Software Package の CD-ROM を、コンピュータの CD-ROM ドライブに挿入する。
しばらくすると、インストール画面が表示されます。

❺

[METAZA Driver インストール] をクリックする。
[ドライバのセットアップ] 画面が表示されます。[ユーザーアカウント制御] 画面が表示されたら、[はい] をクリックしてください。

❻

① [インストール] を選択する。
② [機種名] を選択する。
③ [USB] を選択する。
④ [開始] をクリックする。
以降、画面の指示に従ってインストールを進めてください。
[Windows セキュリティ] 画面が表示されたら、[このドライバーソフトウェアをインストールします (I)] をクリックしてください。

❼

図の画面が表示されたら、[完了] をクリックする。

❽ 

① [機種名] と [ポート] が USB であることを確認する。
② [閉じる] をクリックする。
[機種名] と [ポート] に誤りがあった場合は、METAZA ドライバをアンインストールして、再度インストールをしてください。

❾ 

① 機器とコンピュータを接続ケーブルで接続する。
② 機器の電源をオンにする。
デスクトップに図が表示されたらインストール作業終了です。

METAZA ドライバをアンインストールする

手順

❶ 機器の電源をオフにする。

❷ [スタート] メニューから、[コントロールパネル] → [プログラムのアンインストール] をクリックする。

❸

① [名前] の中から、機器の機種名があるドライバを選択する。
② [アンインストール] をクリックする。

❹

図の画面が表示されたら、[はい] をクリックする。
選択したドライバが削除されます。
[ユーザーアカウント制御] 画面が表示されたら、[はい] をクリックしてください。

❺ Roland Software Package の CD-ROM を、コンピュータの CD-ROM ドライブに挿入する。
しばらくすると、インストール画面が表示されます。

❻

[METAZA Driver インストール] をクリックする。
[ユーザーアカウント制御] 画面が表示されたら、[はい] をクリックしてください。

❼ 

① [アンインストール] を選択する。
② [機種名] を選択する。
機器の機種名を選択してください。
③ [開始] をクリックする。
アンインストールが開始されます。

❽ 

図の画面が表示されたら、[はい] をクリックする。
コンピュータが再起動します。再起動したら、アンインストールは終了です。

Windows® は、米国 Microsoft® Corporation の米国およびその他の国における登録商標または商標です。
その他、記載されている会社名、製品名は、各社の商標および登録商標です。

METAZA Driver InstIlation Guide (Windows 7)

The METAZA Driver has become compliant with Windows 7.
This document includes instructions to install and uninstall the METAZA driver under Windows 7.

Compatible Editions

- Windows 7 Home Premium (32-bit edition or 64-bit edition)
- Windows 7 Professional (32-bit edition or 64-bit edition)

※ The operation in the Windows XP mode has not been verified.

※ For the latest information, see the Roland DG Corp. website (http://www.rolanddg.com).

Installing the METAZA Driver

Notice

If any older version of the METAZA driver has been installed, make sure to uninstall it first and then to install the latest edition of the METAZA driver. Otherwise, the METAZA driver may fail to work properly. For information on how to uninstall the METAZA driver, see “Uninstalling the METAZA Driver” in the next section.

Procedure

1. ① Turn off the power to your Roland DG product (hereinafter called the “Device”) and computer.
   ② Disconnect the cables between the Device and the computer.
   ③ Turn on the computer.
2. Log on to Windows 7 as an “Administrator” or a member of “Administrators” group.
3. If any older version of the METAZA driver is installed, uninstall it.
   ☞ "Uninstalling the METAZA Driver"
4. Insert the Roland Software Package CD-ROM into the computer.
   The install menu appears on the screen after a short time.
5. 

   Click [METAZA Driver Install].
   [Driver Setup] window appears on the screen. When [User Account Control] is displayed on the screen, click [YES].
6. 

   ① Select [Install].
   ② Select an applicable [Model].
   ③ Select [USB].
   ④ Click [Start].
   Proceed further with the installation as following the instructions displayed on the screen. When [Windows Security] appears on the screen, click [Install this driver software anyway].
7. 
Roland METAZA DRIVER [MPX-XX] - InstallShield Wizard
InstallShield Wizard Completed
The InstallShield Wizard has successfully installed Roland METAZA DRIVER [MPX-XX]. Click Finish to exit the wizard.
< Back
Finish
Cancel
   When the window shown on the left appears on the screen, click [Finish].
8. 

   ① Confirm [Model] is correct and "USB" is selected for [Port].
   ② Click [Close].
   If [Model] and [Port] are not correctly selected, uninstall the METAZA driver, and then install it again.
9.

   ① Connect the Device and the computer with the connection cable.
   ② Turn on the Device.
   The install process is complete when the icon shown on the left appears on the desktop.

Uninstalling the METAZA Driver

Procedure

1. Turn off the Device.
2. From the [Start] menu, click [Control Panel], and then click [Uninstall a program].
3. 

   ① Select the driver with the applicable model of the Device from the list of [Name].
   ② Click [Uninstall].
4.
Programs and Features
Are you sure you want to uninstall Roland METAZA DRIVER [MPX-XX]?
In the future, do not show me this dialog box
Yes
No
   When the window shown on the left appears on the screen, click [Yes].
   The selected driver is deleted. When [User Account Control] is displayed on the screen, click [YES].
5. Insert the Roland Software Package CD-ROM into the computer.
   The install menu appears on the screen after a short time.
6. 

   Click [METAZA Driver Install].
   When [User Account Control] is displayed on the screen, click [YES].
7.

   ① Select [Uninstall].
   ② Select an applicable [Model].
   Select a model name of your Device.
   ③ Click [Start].
   Uninstallation starts.
8.

   When the window shown on the left appears on the screen, click [Yes].
   The computer restarts. When the reboot is finished, the process of uninstallation is complete.

Windows® is a registered trademark or trademark of Microsoft® Corporation in the United States and/or other countries.
Company names and product names are trademarks or registered trademarks of their respective holders.

Copyright © 2010 Roland DG Corporation

R1-100120

1000006880